

## 1. Overview

The block diagram below illustrates the basic connections between the AFI Series 86C POTS fiber interface and the Viking E-30 Entry Phone and the SRC-1 Gate Entry Controller.

The TBB-1B Talk Battery Booster may be needed if the resulting voltage at the E-30 drops below the minimum requirement. AFI's MT-86C will provide ~ 24Vdc open circuit at the Line In.

## 2. Detail

