


PELCO  
KEYBOARD

- |   |                   |
|---|-------------------|
| 7 | RS422 INPUT + #2  |
| 8 | RS422 INPUT - #2  |
|   | GROUND            |
| 1 | RS422 OUTPUT + #2 |
| 2 | RS422 OUTPUT - #2 |
| 5 | +12V              |
| 4 | GROUND            |
| 6 | -12V              |

PELCO  
KEYBOARD

- |                   |        |
|-------------------|--------|
| RS422 INPUT + #1  | 7      |
| RS422 INPUT - #1  | 8      |
| GROUND            |        |
| RS422 OUTPUT + #1 | 1      |
| RS422 OUTPUT - #1 | 2      |
| VIDEO OUTPUT      | 5      |
|                   | 4      |
|                   | 6      |
|                   | +12V   |
|                   | GROUND |
|                   | -12V   |

OPTICAL I/O



OLI - OPTICAL LEVEL INDICATOR:  
INDICATOR IS GREEN WHEN PROPER  
LEVEL IS PRESENT. IT IS RED WHEN  
SIGNAL IS MISSING OR AT INCORRECT  
LEVEL.

 <b>afi</b> american fibertek 120 BELMONT DRIVE SOMERSET N.J.	DATE: 02 JUNE 08		RR-1440-184 CUSTOMER ASSEMBLY DRAWING		
	ACAD FN.: RR-1440-184 CC				
	SCALE: NONE	DWG BY: BLB	DWG. NO.:	SH. 1 OF 1	REV.: