


OLI – OPTICAL LEVEL INDICATOR:  
 INDICATOR IS GREEN WHEN PROPER  
 LEVEL IS PRESENT. IT IS RED WHEN  
 SIGNAL IS MISSING OR AT INCORRECT  
 LEVEL.

 american fibertek 120 BELMONT DRIVE SOMERSET N.J.	DATE: 09 SEPT 08		RR-3600P CUSTOMER ASSEMBLY DRAWING		
	ACAD FN.: RR-3600P CC				
	SCALE: NONE	DWG BY: BLB	DWG. NO.:	SH. 1 of 1	REV.: