


CONTACT TX/RX INDICATOR:
INDICATOR IS GREEN WHEN
CONTACT IS CLOSED. OFF
WHEN CONTACT IS OPEN.

OLI — OPTICAL LEVEL INDICATOR: INDICATOR IS GREEN WHEN PROPER SIGNAL/LEVEL IS PRESENT. IT IS RED WHEN SIGNAL IS MISSING OR AT AN INCORRECT LEVEL.




SCALE:

NONE

DWG BY:

BLB

DATA SWITCH SETTINGS						
1	2	3	4	5	6	ON=DOWN / OFF=UP
OFF	OFF	OFF	ON	ON	OFF	RS485-4W / MANCHESTER (FACTORY SHIPPED)
OFF	OFF	OFF	OFF	ON	ON	RS485-2W
OFF	OFF	OFF	ON	OFF	OFF	RS422
OFF	OFF	OFF	OFF	OFF	OFF	RS232
NOT USED			DATA			



DWG. NO.:

OPTICAL CONNECTION: ST SINGLEMODE

REV.:

CHK.:



DATE: 04 NOV 14 MTX-459-ST

ACAD FN.:
MTX-459-ST CC CUSTOMER ASSEMBLY DRAWING