



LED INDICATORS:

UTP LINK/ACT: GREEN: 1000 BASE-T
 RED: 100 BASE-TX
 AMBER: 10 BASE-T

BLINK: UTP LINK IS ESTABLISHED AND ACTIVITY IS ON UTP PORT.
 SOLID: UTP LINK IS ESTABLISHED BUT NO ACTIVITY IS ON UTP PORT.
 OFF: UTP LINK IS NOT ESTABLISHED.

FIBER LINK/ACT: 1000 BASE-LX FIBER LINK AND ACTIVITY.

BLINK (GREEN): FIBER LINK IS ESTABLISHED AND ACTIVITY IS ON FIBER.
 SOLID (GREEN): FIBER LINK IS ESTABLISHED BUT NO ACTIVITY IS ON FIBER.
 OFF: FIBER LINK IS NOT ESTABLISHED.

OLI: RED: DC POWER IS ON BUT OPTICAL POWER IS MISSING OR AT INCORRECT LEVEL.
 GREEN: DC POWER IS ON AND OPTICAL POWER IS AT PROPER LEVEL.

 120 BELMONT DRIVE SOMERSET N.J.	DATE: 28 OCT 09		MX-48-LX-SL-SC CUSTOMER CONNECTION		
	ACAD FN.: MX-48-LX-SL-SC CC				
	SCALE:	DWG BY: CLQ	DWG. NO.:	SH. OF	REV.: