


POWER:  
INDICATOR IS GREEN WHEN DC  
POWER IS PRESENT. IT IS OFF WHEN  
NO POWER IS PRESENT.

DATA RX/TX:  
INDICATOR IS RED AND INDICATES  
DATA ACTIVITY. INDICATOR IS OFF  
WHEN NO ACTIVITY IS PRESENT.



FACTORY SHIPPED SETTINGS:

- RS485 (4 WIRE)
- 4 WIRE INPUT TERMINATION
- NO BIAS

TO SELECT OTHER SETTINGS; MOVE SWITCHES  
TO THE APPROPRIATE POSITION USING A  
SMALL SCREWDRIVER BLADE.

	SWITCH FUNCTION	OFF (UP)	ON (DOWN)	FACTORY SHIPPED
8	TERMINATION 4W IN, 2W I/O	HI Z	120 OHM	DOWN
7	INPUT BIAS	NO BIAS	BIASED	UP
6				
5	TERMINATION 4W OUTPUT	HI Z	120 OHM	UP
4	OUTPUT BIAS	NO BIAS	BIASED	UP
3				
2	2W/4W	4W	2W	UP
1	FACTORY USE ONLY			DOWN

 120 BELMONT DRIVE SOMERSET N.J.	DATE: 05 MAR 08		MX-485 CUSTOMER CONNECTION			
	ACAD FN: MX-485 CC					
	SCALE: NONE	DWG BY: BLB	DWG. NO.:	SH. OF	REV.:	CHK.: