



OLI – OPTICAL LEVEL INDICATOR:
 INDICATOR IS GREEN WHEN PROPER
 LEVEL IS PRESENT. IT IS RED WHEN
 SIGNAL IS MISSING OR AT INCORRECT
 LEVEL.

TX1, RX1, TX2, RX2 INDICATORS:
 INDICATORS ARE RED AND
 INDICATE DATA ACTIVITY.

 120 BELMONT DRIVE SOMERSET N.J.	DATE: 12 DEC 07		MTX-486 CUSTOMER CONNECTION		
	ACAD FN.: MTX-486 CC				
	SCALE:	DWG BY: BLB	DWG. NO.:	SH. OF	REV.: