



OLI – OPTICAL LEVEL INDICATOR:  
 INDICATOR IS GREEN WHEN PROPER  
 LEVEL IS PRESENT. IT IS RED WHEN  
 SIGNAL IS MISSING OR AT INCORRECT  
 LEVEL.

TX1, RX1, TX2, RX2 INDICATORS:  
 INDICATORS ARE RED AND  
 INDICATE DATA ACTIVITY.

 120 BELMONT DRIVE SOMERSET N.J.	DATE: 02 JULY 09		MTX-486SL CUSTOMER CONNECTION		
	ACAD FN.: MTX-486SL CC				
	SCALE:	DWG BY: BLB	DWG. NO.:	SH. OF	REV.: