


} N.C.  
 } N.C.  
 } MASTER +  
 } MASTER -  
 } CONTACT IN  
 } CONTACT IN

OPTICAL I/O



OLI – OPTICAL LEVEL INDICATOR:  
 INDICATOR IS GREEN WHEN PROPER  
 LEVEL IS PRESENT. IT IS RED WHEN  
 SIGNAL IS MISSING OR AT INCORRECT  
 LEVEL.

 american fibertek 120 BELMONT DRIVE SOMERSET N.J.	DATE: 28 MAY 08		RR-89P STENTOFON 9600 MASTER INTERCOM INTERFACE CUSTOMER ASSEMBLY DRAWING		
	ACAD FN.: RR-89P CC				
	SCALE: NONE	DWG BY: BLB	DWG. NO.:	SH. 1 OF 1	REV.: