



OLI - OPTICAL LEVEL INDICATOR:  
 INDICATOR IS GREEN WHEN PROPER  
 LEVEL IS PRESENT. IT IS RED WHEN  
 SIGNAL IS MISSING OR AT INCORRECT  
 LEVEL.

 american fibertek 120 BELMONT DRIVE SOMERSET N.J.	DATE: 28 MAY 08		RR-89P-EL STENTOFON 9600 MASTER INTERCOM INTERFACE CUSTOMER ASSEMBLY DRAWING		
	ACAD FN.: RR-89P-EL CC				
SCALE: NONE	DWG BY: BLB	DWG. NO.:	SH. 1 OF 1	REV.:	CHK.: