

AUDIO TX/RX INDICATORS:

INDICATOR IS GREEN WHEN PROPER SIGNAL LEVEL IS PRESENT. OFF WHEN SIGNAL MISSING OR AT AN INCORRECT LEVEL.

CONTACT TX/RX INDICATORS:


INDICATOR IS GREEN WHEN CONTACT IS CLOSED. OFF WHEN CONTACT IS OPEN.

VLI - VIDEO LEVEL INDICATOR:

OLI - OPTICAL LEVEL INDICATOR:

SYNC - SYNC INDICATOR:

INDICATOR IS GREEN WHEN PROPER SIGNAL/LEVEL IS PRESENT. IT IS RED WHEN SIGNAL IS MISSING OR AT AN INCORRECT LEVEL.

 american fibertek 120 BELMONT DRIVE SOMERSET N.J.	DATE: 21 AUG 09		MR-91P889SL			
	ACAD FN.: MR-91P889SL CC		CUSTOMER ASSEMBLY DRAWING			
	SCALE: NONE	DWG BY: CLQ	DWG. NO.:	SH. OF	REV.:	CHK.: <i>SK</i>