



AUDIO TX/RX INDICATORS:
INDICATOR IS GREEN WHEN PROPER SIGNAL LEVEL IS PRESENT. OFF WHEN SIGNAL MISSING OR AT AN INCORRECT LEVEL.

OLI - OPTICAL LEVEL INDICATOR:
SYNC - SYNC INDICATOR:
INDICATOR IS GREEN WHEN PROPER SIGNAL/LEVEL IS PRESENT. IT IS RED WHEN SIGNAL IS MISSING OR AT AN INCORRECT LEVEL.

THE DATA CHANNEL IS USER CONFIGURABLE.

DATA SWITCH SETTINGS ON=DOWN OFF=UP						DATA CHANNEL CONFIGURATION
1	2	3	4	5	6	
OFF	OFF	OFF	OFF	X	X	RS485-4W (FACTORY SHIPPED)
OFF	OFF	OFF	OFF	X	X	RS485-2W
OFF	OFF	OFF	OFF	X	X	RS422
OFF	OFF	OFF	OFF	X	X	RS232
CHANNEL1						

 american fibertek 120 BELMONT DRIVE SOMERSET N.J.	DATE: 11 MAR 16		MR-9P8SL-LH CUSTOMER ASSEMBLY DRAWING			
	ACAD FN.: MR-9P8SL-LH CC					
	SCALE: NONE	DWG BY: BLB	DWG. NO.:	SH. OF	REV.:	CHK.: <i>SK</i>