


AUDIO TX/RX INDICATORS:
 INDICATOR IS GREEN WHEN
 PROPER SIGNAL LEVEL IS
 PRESENT. OFF WHEN SIGNAL
 MISSING OR AT AN INCORRECT
 LEVEL.

OLI - OPTICAL LEVEL INDICATOR:
SYNC - SYNC INDICATOR:
 INDICATOR IS GREEN WHEN
 PROPER SIGNAL/LEVEL IS
 PRESENT. IT IS RED WHEN
 SIGNAL IS MISSING OR AT
 AN INCORRECT LEVEL.

 american fibertek		DATE:	04 APR 14	MT-9P8(SL) CUSTOMER ASSEMBLY DRAWING	
		ACAD FN.:	MT-9P8(SL) CC		
120 BELMONT DRIVE SOMERSET N.J.		SCALE:	NONE	DWG BY:	JPK
		DWG. NO.:		SH. OF	
		REV.:		CHK.:	