




AUDIO TX/RX INDICATORS:
 INDICATOR IS GREEN WHEN PROPER SIGNAL LEVEL IS PRESENT. OFF WHEN SIGNAL MISSING OR AT AN INCORRECT LEVEL.

OLI - OPTICAL LEVEL INDICATOR:
SYNC - SYNC INDICATOR:
 INDICATOR IS GREEN WHEN PROPER SIGNAL/LEVEL IS PRESENT. IT IS RED WHEN SIGNAL IS MISSING OR AT AN INCORRECT LEVEL.



 american fibertek 120 BELMONT DRIVE SOMERSET N.J.	DATE:	03 SEPT 14		RR-9P8(SL)	
	ACAD FN.:	RR-9P8(SL) CC		CUSTOMER ASSEMBLY DRAWING	
SCALE:	DWG BY:	DWG. NO.:	SH. OF	REV.:	CHK.:
NONE	BLB				SK