


AUDIO TX/RX INDICATORS:
INDICATOR IS GREEN WHEN PROPER SIGNAL LEVEL IS PRESENT. OFF WHEN SIGNAL IS MISSING OR AT AN INCORRECT LEVEL.


OLI - OPTICAL LEVEL INDICATOR:
SYNC - SYNC INDICATOR:
INDICATOR IS GREEN WHEN PROPER SIGNAL/LEVEL IS PRESENT. IT IS RED WHEN SIGNAL IS MISSING OR AT AN INCORRECT LEVEL.

CONTACT TX/RX INDICATOR:
INDICATOR IS GREEN WHEN CONTACT IS CLOSED. OFF WHEN CONTACT IS OPEN.

AUDIO CONNECTIONS



CONTACT CONNECTIONS



 120 BELMONT DRIVE SOMERSET N.J.	DATE: 09 APR 13		MT-9P89(SL)		
	ACAD FN.: MT-9P89(SL) CC		CUSTOMER ASSEMBLY DRAWING		
SCALE: NONE	DWG BY: BLB	DWG. NO.:	SH. OF	REV.:	CHK.: <i>SK</i>