

NOTE: SEE SHEET 2 FOR D-SUB 26 ADAPTOR DETAIL.


CONTACT IN CH1 TO CH 16:
 THESE PROVIDE 16 CONTACT CLOSURE INPUT CONNECTIONS. CLOSING THE RESPECTIVE CONTACT CLOSURE INPUT CONNECTIONS CAUSES THE RESPECTIVE RELAYS IN THE MR/RR-82 TO SWITCH FROM THE DEFAULT STATE TO (NORMALLY OPEN CONNECTIONS ARE CLOSED) AND (NORMALLY CLOSED CONNECTIONS ARE OPEN).

CONTACT1 TO CONTACT16 – CONTACT CLOSURE INPUT INDICATORS:
 GREEN INDICATES THAT THE CONTACT INPUT CONNECTION IS CLOSED.

OLI – DC POWER:
 GREEN INDICATES THAT DC POWER IS ON.

RESET PUSH BUTTON:
 PRESSING THE MOMENTARY PUSH BUTTON CAUSES ALL THE CONTACT OUTPUTS AT THE MR/RR-82 UNITS TO TEMPORARILY SWITCH TO THEIR DEFAULT STATES (NORMALLY OPEN CONNECTIONS ARE OPEN; NORMALLY CLOSED CONNECTIONS ARE CLOSED). THIS IS USED PRIMARILY FOR TESTING PURPOSES.

| | | | | | |
|--|--------------------|-------------|---------------------------|------------|-------|
| afi american fibertek 120 BELMONT DRIVE SOMERSET N.J. | DATE: 14 MAY 08 | | RT-82 | | |
| | ACAD FN.: RT-82 CC | | CUSTOMER ASSEMBLY DRAWING | | |
| | SCALE: NONE | DWG BY: CLQ | DWG. NO.: | SH. 1 OF 2 | REV.: |



afi
 american fibertek
 120 BELMONT DRIVE SOMERSET N.J.

DATE: 14 MAY 08

ACAD FN.: RT-82 CC

SCALE: NONE DWG BY: CLQ

RT-82
CUSTOMER ASSEMBLY DRAWING

DWG. NO.: REV.: CHK.: *SK*

SH. 2 OF 2